

under supervision of

OMNIHANDLING

SÃO TOMÉ • FPST PRINCIPE • FPPR

Ramp & Aircraft | Pax & Crew Lounge
Transfers | Catering | Hotels

HANDLING FACILITIES

Operating hours - 24/7

Cards accepted - Visa, Mastercard, AMEX, AVCARD

Executive Handling Supervision

(+351) 91 522 02 10
saotome@omnihandling.com



SAO TOME (FPST)

Location - 4km NW of town
Local time - UTC/GMT +1 hour (no DST)
Airport operating hours - Mon.-Fri. 07:00-16:00Z
(O/T 2hrs PNR)
Runway - 11/29 (2150x45m)
Elevation - 10m (33 ft)
Fuel - Jet A1
Fire category - 5
Airport of entry - Yes

PRINCIPE (FPPR)

- 4km NNW of town
- UTC/GMT +1 hour (no DST)
- Mon.-Fri. 06:00-16:30Z
- 18/36 (1320x30m)
- 180m (591 ft)
- NO FUEL
- Nil
- Yes